

Universal wet and pressure sensitive adhesive

# UZIN KE 2000 S

Dispersion adhesive for all common resilient coverings, textile coverings, wall coverings and UZIN insulation/installation underlays

**MAIN APPLICATION FIELD:**

- ▶ homogeneous and heterogeneous PVC or CV floor coverings in sheets and tiles
- ▶ rubber floor coverings in sheets (e.g. noraplan® up to 4 mm) and floor coverings with foam or acoustic backing
- ▶ textile floor coverings with all common backings
- ▶ light weight needle punch or woven carpet
- ▶ luxury vinyl tiles or design floors
- ▶ linoleum in sheets up to 3.2 mm

**SUITABLE ON / FOR:**

- ▶ absorbent and levelled substrates
- ▶ dense, non absorbent substrates with the pressure-sensitive method (only PVC and CV, no LVT)
- ▶ dense, non absorbent substrates with the double-drop method (only PVC, CV and rubber)
- ▶ warm water underfloor heating systems
- ▶ exposure to castor wheels in accordance with DIN EN 12 529
- ▶ for wet shampooing and spray extraction cleaning according to RAL 991 A2
- ▶ normal wear in residential, commercial and industrial locations



**PRODUCT BENEFITS/FEATURES:**

UZIN KE 2000 S is a strong dispersion adhesive with short waiting time and long working time. It can be used as a pressure sensitive or wet-set adhesive and used via the double drop method. For use on floors and walls. For interior use.

- ▶ short waiting time
- ▶ excellent application properties
- ▶ good grab with stringing




**TECHNICAL DATA:**

Packaging	plastic bucket
Pack size	14 kg, 6 kg, 2 kg
Shelf life	min. 12 months
Color, wet	cream white
Color, dry	transparent
Consumption	180 - 380 g/m <sup>2</sup>
Open time	10 - 45 minutes*
Working time	15 - 120 minutes*
Minimum application temperature	15 °C at ground level
Loadable	after 24 hours*
Joint sealing	after 24 hours*
Final strength	after 3 days*

\*At 20 °C and 65% relative humidity, depending on the type of floor covering and the absorbency of the substrate.

\*\*Max. acceptable consumption for shipbuilding (IMO): 320 g/m<sup>2</sup>



## EXTENDED APPLICATIONS:

- ▶ floor coverings free of PVC and plasticizers (e.g. Amtico Cirro, Haro Disano, Tarkett IQ One)
- ▶ Enomer® flooring sheets
- ▶ PUR flooring (e.g. wineo PURLINE)
- ▶ wall coverings (e.g. PVC coverings in bathrooms or gyms)
- ▶ corkment as well as all UZIN installation and insulation underlays

## SUBSTRATE PREPARATION:

The substrate must be sound, load-bearing, dry, free from cracks and materials (dirt, oil, grease) that would impair adhesion. The surface must be vacuumed, primed and smoothed. Suitable primers and compounds can be found in the UZIN Product Guide. Test the substrate in accordance with applicable standard or notices and report any deficiencies. Allow the primer and levelling compound to dry completely.

The datasheets for other used products have to be observed.

## APPLICATION:

1. Apply an even coat of adhesive onto the substrate using a suitable notched trowel and allow to dry partially according to the application amount, the indoor climate, the absorbency of the substrate and the type of floor covering. Do not apply more adhesive than can be laid with good transfer onto the back of the covering within the working time.
2. Install the floor covering within a short open time and ensure the adhesive ridge is pressed out. Rub in or roll over and apply weight against any flooring deformation. Ensure that air is not trapped under the covering. Allow the area to rest for 20 minutes and then roll over again and rub in at edge and seams.

**Wet Set Adhesive Method:** Install the floor covering while the adhesive is still wet, roll and ensure there is no trapped air. Please note that if the floor is laid in the wet adhesive there will be no or little initial tack.

**Double-Drop-Method:** Install the floor covering into the wet adhesive and rub in or roll. Pull back immediately and allow the backing of floor covering and substrate to partially dry until a tack can be felt (finger test see picture below). The adhesive ridge should not be visible. Reinstall the floor covering and roll to ensure there is no trapped air.

**Wall applications:** Apply the adhesive with a nylon roller onto the prepared wall, spread immediately with an appropriate notched trowel and allow to tack. Apply the covering and rub over.

**Contact applications:** Depending on the type of covering apply the adhesive with a trowel or a roller on the back of the floor covering and on the substrate. After the adhesive dries, install floor covering and roll over.

3. Remove adhesive residues while fresh with water.




## CONSUMPTION INFORMATION:

Belagsart/ Belagsrücken	Zahnung	Verbrauch* ca.	IMO**
Smooth, e.g. CV floor coverings	A5	180 - 200 g/m <sup>2</sup>	yes
Smooth, e.g. LVT	A1	200 - 280 g/m <sup>2</sup>	yes
Slightly structured, e.g. PVC, LVT, rubber	A2	250 - 320 g/m <sup>2</sup>	yes
Structured, e.g. carpet, linoleum, soft needle punch	B1	320 - 380 g/m <sup>2</sup>	no

\*At 20 °C and 65% relative humidity with tempered adhesive buckets.

\*\*Max. acceptable consumption for shipbuilding (IMO): 320 g/m<sup>2</sup>

## Partial drying and installation time of various pressure-sensitive adhesives:



PVC sheet installation on UZIN NC 170 LevelStar, notch size A 2, at 20 °C and 65 % relative humidity.

The open time required for pressure-sensitive adhesives could be minimised with the raw material choice of the UZIN

KE 2000 S without shortening the installation. This provides greater certainty to the installer and fewer restrictions with the different construction site conditions. The floor covering can therefore be installed earlier with many applications. The installer becomes significantly faster through the earlier installation option; the adhesive is thereby better pressed out. This has a positive effect on the overall look of the installed floor covering area; the floor covering lies flatter and quieter.

## FLASH-OFF AND INSTALLATION TIME FOR DIFFERENT TYPES OF COVERINGS:

Floor covering on levelled substrates "Wet / Semi-wet application"	Trowel notch	Waiting time*	Working time*
CV floor coverings, LVT	A5	5 - 15 minutes	10 - 20 minutes
PVC floor coverings, rubber	A2	10 - 20 minutes	10 - 20 minutes
Textile floor coverings, linoleum	B1	15 - 25 minutes	10 - 30 minutes
Needle punch	B2	15 - 25 minutes	20 - 45 minutes

Floor covering on dense substrates "Pressure sensitive application"	Trowel notch	Waiting Time*	Working Time*
PVC floor coverings, e.g. on UZIN KR 410 or dense installation underlays	A5	30 - 40 minutes	1 - 2 hours

Floor covering on dense substrates "Double drop application"	Trowel notch	Waiting time*	Working time*
Rubber on smooth, dense coatings	A5	10 minutes, remove floor covering again then 20 minutes	45 minutes

\*At 20 °C and 65% relative humidity.

## IMPORTANT NOTES:

- ▶ A shelf life of 12 months when stored in moderately cool conditions, in the original packaging. Protect from frost. Carefully and tightly reseal opened containers and use the contents quickly. Allow containers to come to room temperature before use.
- ▶ Best applied between 18 - 25 °C, with the floor temperature above 15 °C and relative air humidity below 65%. Low temperatures and high air humidity lengthen the working and drying time. Whilst high temperatures and low air humidity shorten the working and drying time.
- ▶ Non-absorbent substrates extend the flash-off time can be shortened by means of the double-drop method. In this process, the adhesive is applied with a notched trowel, the floor covering is inserted and immediately knocked back again. The flooring can then be placed in the adhesive film and rolled on.
- ▶ Humid substrates may cause secondary emissions and odours. Therefore, ensure the compound is dry before applying the adhesive.
- ▶ Installations onto substrates with old adhesive residues may cause interactions and lead to unpleasant odours. Ideally these should be removed completely. In all situations adhesive residues must be remedied via the use of primers and coatings of compound at least 3 mm thick.

- ▶ Before installing, the floor covering must be adequately acclimatised to the indoor climate and free from tension.
- ▶ In extreme temperatures due to exposure from light, heavy mechanical strain from pallet trucks, fork lifts, etc. or when exposed to moisture from above, a synthetic resin adhesive such as UZIN KR 430 must be used. Obtain application advice if in doubt.
- ▶ Please check the adhesive recommendations (online) or obtain application advice when installing chlorine-free floor coverings.
- ▶ When sealing, cleaning and maintaining the floor covering, products from the UZIN Care range can be used (UZIN Basic Cleaner, UZIN Turbo Protect Plus, UZIN Resilient Care, UZIN Refresher). For further information please refer to the product data sheets.
- ▶ Follow the generally acknowledged rules of the trade and technology for the installation of floor covering in respect of the applicable national standards (e.g. END, DIN, OE, SIA, etc.)

## SEALS OF QUALITY & ECOLABELS:

- ▶ Solvent-free
- ▶ EMICODE EC 1 PLUS / Very low emission
- ▶ DE-UZ 113 / Environmentally friendly because of low emissions

## COMPOSITION:

Polymer dispersion, modified resins, preservation agents, mineral aggregates, additives and water.

## PROTECTION OF THE WORKPLACE AND THE ENVIRONMENT:

Solvent-free. Use of barrier cream and ventilation of the work area are recommended. Keep out of the reach of children. Do not eat, drink or smoke during the installation. After contact with eyes or skin, wash immediately with plenty of water. Do not allow dispersal into drains, sewers or ground. Rinse tools with water and soap immediately after use. When fully dried presents no physiological or ecological risk. Basic prerequisites for best possible indoor air quality following floor covering work are conformity to standards of the working conditions, as well as thoroughly dry substrate, primer and smoothing compound. Product contains isothiazolinones, Bronopol. Hotline for allergy information +49 731 4097-0.

## DISPOSAL:

Where possible, collect product residues and re-use. Do not allow dispersal into drains, sewers or ground. Empty, scraped and drip-free containers are recyclable. Containers with liquid residue, as well as the liquid product, are classed as Special Waste. Dried product residues are classed as Construction Waste.